


# Instruction of Print Head Disassembly

## 列印頭拆解方式說明 / 打印头拆解方式说明

Step 1 : Push both forks of TPH module equally to remove the TPH module out of the linkage

步驟一：平推列印頭模組到兩個卡榫離開卡槽



步骤一：平推列印头模组到两个卡榫离开卡槽



Ste 2 : Disconnect the TPH cable after the TPH is removed from the linkage.

步驟二：列印頭離開卡槽後，拆除列印頭連接線

步骤二：打印头离开卡槽後，拆除打印头连接线



Reverse the steps above to install the new TPH module back

反向上述步驟安裝回新的列印頭模組 / 反向上述步驟安裝回新的打印头模组



Note : During disassembly and installation , please be aware of the print head .

注意：在拆解和安裝過程中，請勿傷及列印頭 / 注意：在拆解和安裝過程中，請勿傷及打印头